






Exposed part for single-lever bath shower mixer CHRONOS_CR014200

MODEL **CR014200**

Exposed part for single-lever bath shower mixer,handshower holder on column,Brass D.24mm minimalistic one spray handshower,150 cm smooth SUPREME Flexible Hose,without concealed part (for item ZB004510)

AVAILABLE FINISHINGS

-  **21** 21 Chrome
-  **2F** 2F Brushed Nickel
-  **2Q** 2Q Black Titanium



CHARACTERISTICS

- Cartridge Spare Parts **ZZ95409000**
- 35 mm Cartridge**
- Installation **Concealed**
- Required concealed parts **ZB004510**



EcoStop

EcoStop feature limits water flow to approximately 50% of maximum output with one point of resistance on setting. Push slightly past the middle stop only when full water output is required. This will save water up to 50%.




Concealed part single lever free-standing CONCEALED_ZB004510

MODEL **ZB004510**

Floor mounted concealed part, for free-standing mixer

AVAILABLE FINISHINGS

 **04** 04 Without finishing



CHARACTERISTICS

Installation	Concealed
Concealed	1



2026-04-26