






## Exposed part for single-lever bath shower mixer CHRONOS\_CR014200

MODEL **CR014200**

Exposed part for single-lever bath shower mixer,handshower holder on column,Brass D.24mm minimalistic one spray handshower,150 cm smooth SUPREME Flexible Hose,without concealed part (for item ZB004510)

### AVAILABLE FINISHINGS

-  **21** 21 Chrome
-  **2F** 2F Brushed Nickel
-  **2Q** 2Q Black Titanium



### CHARACTERISTICS

- Cartridge Spare Parts **ZZ95409000**
- 35 mm Cartridge**
- Installation **Concealed**
- Required concealed parts **ZB004510**



### EcoStop

EcoStop feature limits water flow to approximately 50% of maximum output with one point of resistance on setting. Push slightly past the middle stop only when full water output is required. This will save water up to 50%.




**Concealed part single lever free-standing CONCEALED\_ZB004510**

MODEL **ZB004510**

Floor mounted concealed part, for free-standing mixer

AVAILABLE FINISHINGS

 **04** 04 Without finishing



CHARACTERISTICS

Installation	<b>Concealed</b>
Concealed	<b>1</b>



2026-04-09