


# Single lever sink mixer KITCHEN



218 Ø 32 CH.11 G3/8"





## **EcoStop**

EcoStop feature limits water flow to approximately 50% of maximum output with one point of resistance on setting. Push slightly past the middle stop only when full water output is required. This will save water up to 50%.



Single lever sink mixer, swivel spout, G.3/8" stainless steel flexible hoses

## **AVAILABLE FINISHINGS**



21 21 Chrome

#### **CHARACTERISTICS**

Cartridge Spare Parts ZZ95409000

35 mm Cartridge



2024-05-06