

Single lever sink mixer ES with pull out handspray KITCHEN_AH000575



Ø 24 200 200 Ø 42 Ø 34 350 G.3/8"

EcoStop

EcoStop feature limits water flow to approximately 50% of maximum output with one point of resistance on setting. Push slightly past the middle stop only when full water output is required. This will save water up to 50%.



EnergySave

Thanks to the EnergySave device, only cold water will be drawn if the lever is operated in the central lever is operated in the central position, so that the water heater will not be engaged and no hot water wasted, leading to considerable savings in energy and costs. The temperature can be adjusted by rotating the lever to the left, until the desired temperature is reached.

MODEL AH000575

Single lever sink mixer ES with pull out handspray, swivel spout, 2 sprays handshower, 175 cm nylon flexible hose

AVAILABLE FINISHINGS



21 21 Chrome



2F 2F Brushed Nickel



40 40 Matt Black

CHARACTERISTICS

Cartridge Spare Parts


ZZ95409000

35 mm Cartridge





Single lever sink mixer ES with pull out handspray KITCHEN_AH000575



AH000575

https://en.huberitalia.com/single-lever-sink-mixer-es-with-pull-out-handspray-kitchen-ah000575

2024-12-22