

### Single lever sink mixer ES with pull out handspray KITCHEN\_AH000575



# Ø 24 200 200 Ø 42 Ø 34 350 G.3/8"

#### **EcoStop**

EcoStop feature limits water flow to approximately 50% of maximum output with one point of resistance on setting. Push slightly past the middle stop only when full water output is required. This will save water up to 50%.



#### **EnergySave**

Thanks to the EnergySave device, only cold water will be drawn if the lever is operated in the central lever is operated in the central position, so that the water heater will not be engaged and no hot water wasted, leading to considerable savings in energy and costs. The temperature can be adjusted by rotating the lever to the left, until the desired temperature is reached.

#### **MODEL** AH000575

Single lever sink mixer ES with pull out handspray, swivel spout, 2 sprays handshower, 175 cm nylon flexible hose

#### **AVAILABLE FINISHINGS**



21 21 Chrome



2F 2F Brushed Nickel



40 40 Matt Black

#### **CHARACTERISTICS**

Cartridge Spare Parts


ZZ95409000

35 mm Cartridge





## Single lever sink mixer ES with pull out handspray KITCHEN\_AH000575



AH000575

https://en.huberitalia.com/single-lever-sink-mixer-es-with-pull-out-handspray-kitchen-ah000575

2024-12-22