

# Single lever washbasin mixer EnergySave H3\_AH000545



# 

## MODEL **AH000545**

Single lever washbasin mixer EnergySave, without waste, G.3/8" stainless steel flexible hoses

### **AVAILABLE FINISHINGS**



21 Chrome



2F 2F Brushed Nickel



40 Matt Black

#### **CHARACTERISTICS**

Cartridge Spare Parts

ZZ96800000

35 mm Cartridge



#### **EcoStop**

EcoStop feature limits water flow to approximately 50% of maximum output with one point of resistance on setting. Push slightly past the middle stop only when full water output is required. This will save water up to 50%.




## **EnergySave**

Thanks to the EnergySave device, only cold water will be drawn if the lever is operated in the central position, so that the water heater will not be engaged and no hot water wasted, leading to considerable savings in energy and costs. The temperature can be adjusted by rotating the lever to the left, until the desired temperature is reached.





# Single lever washbasin mixer EnergySave H3\_AH000545



AH000545

https://en.huberitalia.com/single-lever-washbasin-mixer-energysave-h3-ah000545